



NOTE: WHEN WIRING MULTIPLE FANS TOGETHER WITH 10K-POT YOU CAN EITHER HAVE UP TO 8 FANS OR 400 FEET OF 18 AWG CABLE WHAT EVER HAPPENS FIRST. (WHEN MEASURING 18 AWG CABLE, START FROM THE 1ST FAN TO THE 10K BACK TO THE 1ST FAN AND THEN TO THE OTHER FANS)

1. MOUNT IN STANDARD 2X4 ELECTRICAL JOB BOX
2. ORIENTATION OF THREE LEADS IS IMPERATIVE FOR PROPER FUNCTION WHEN WIRING THE POTENTIOMETER TO AN ELECTRONICALLY COMMUTATED FAN.
3. ELECTRICAL CONNECTIONS SHOULD BE MADE ACCORDING TO THE WIRING DIAGRAM.
4. MOUNT THE CONTROLLER SO THAT THE FAN IT CONTROLS IS VISIBLE FROM THE CONTROLLER.